

OPTION A: Tensioning Ratchets provide easy installation and are permanent.



- Step 1: Brush or sweep portion of joint to insure foreign materials do not interfere with the direct contact between the joint to be sealed and the mastic sealer of the CRETEX WRAP.
- Step 2: Align the collar directly of the joint to where the straps close over the top of the pipe.
- Step 3: Remove the protective plastic film exposing the mastic side to the joint. Wrap the exposed mastic around the joint.
- Step 4: Insert the loose strap and through the take-up shaft. Push down and up on the handle to apply tension, once proper tension achieved push handle down to lock into position. Excess strap may be cut off.
- Step 5: Remove the protective film from the closing flap to cover the tensioning ratchets and straps, completing the joint.

OPTION B: Our Standard Cretexwrap Installation is quick, cost effective and permanent.

