

INFLOW DISH INSTALLATION INSTRUCTIONS

SURFACE PREPARATION – The manhole frame rim shall be cleaned of any loose rust or scale, and dirt any debris with a wire brush before placing the Cretex Inflow Dish upon the rim.

INSTALLATION – No special tools are required to install the Cretex Inflow Dish.

1. Remove manhole cover.
2. Wire brush the rim of the frame to remove any loose rust or scale, dirt and debris. A reasonably smooth, clean surface is required.
3. Place the Cretex Inflow Dish on the manhole frame rim.
4. The Cretex Inflow Dish shall be fully seated around the manhole frame rim.
5. Replace the manhole cover.